

The topical subject

Protection and care of wooden garden furniture

AURO Teak oil No. 102-81

Oil for garden furniture Bangkirai No. 102-85

Oil for garden furniture Natural No. 102-92

Garden furniture cleaner No. 811

Wooden furniture exposed in the garden needs protection

Rain, sun and daily use can damage the wood. Garden furniture made of wood then becomes unattractive or even useless. Protect your garden furniture against the influences of the weather and you will be able to enjoy it for many years to come.

Protection and beauty for your wood

Application of AURO Oils for garden furniture and Teak oil creates a water and soil-resistant surface. The soluble oils in the product are free-breathing and do not flake off. Moisture variations are regulated and weather resistance is improved. The pigmentation gives the surface a fresh colouring and enhances the natural wood tone.



Application

Suitable substrates for application of these oils are clean, dry, grease-free, absorbent wood surfaces, which may also have been treated with some oil previously or show some weathering. We recommend cleaning the garden furniture and sanding it lightly before applying the oil product, or sanding the surface lightly before each application for multiple applications. This smooths out any protruding wood fibres, creating an even substrate surface.

After the product has been stirred, the oils can be applied to open wood surfaces as a first treatment using a non-linting cloth or by means of an even brushing motion. Just dip the cloth into the paint.

Before the product has dried, after 20-30 minutes depending on the ambient temperature, remove extra oil that has not been absorbed into the surface with a strong, absorbent, non-linting cloth - or rub the oil into the wood.

Please turn over!



Teak Oil
No. 102-81



Bangkirai
No. 102-85



Natural
No. 102-92

After a drying period of approx. 24 hours, ventilating well, a second coat, or multiple coats, can be applied with a non-linting cloth. This will intensify the colour tone of the wood and enhance its protective effect. Multiple applications will result in a silky matte surface.

A test is recommended before application to the whole surface, since the effects of the oils - the colour tone and lustre - vary from one type of wood to another.

Handling and cleaning of tools

Products containing drying oils are subject to spontaneous combustion, especially if the cloths are crumpled. Therefore, all used cloths must be laid out separately and smoothly and must not be crumpled or piled. When dry, they can be disposed of with household wastes or reused. Brushes are best cleaned with AURO Thinner No. 191, then washed out with Plantsoap No. 411 and water. A proven method is to massage AURO Plant soap No. 411 into brushes, broad brushes, etc. and to store the tools in the soap solution until the next use. Then rinse out thoroughly with water before use.

Product storage and safety

As with all paints and coatings, store Garden Furniture and Teak Oil in the original packaging in a dry place, closed tightly, cool but protected from frost and out of reach of children. Stored in this way, a storage stability period of 24 months is guaranteed. As a rule, the products can also be used after this period, but a test coat should be applied before using them. As with all paints and varnishes, take appropriate protective measures when applying these oil products, in particular to ensure sufficient ventilation and skin protection.

Garden furniture cleaner No. 811

The strong cleaning power of the Auro Garden furniture cleaner helps you to effectively remove unaesthetic soilings and greying of garden furniture.

Application

Remove coarse grime by brushing or sweeping. Add Garden furniture cleaner to warm water. For medium soiled surfaces, add 3 sealing caps (approx. 25 ml) of cleaner to 5 L of warm water. For the removal of severe soilings raise the dosage accordingly.

Rub down the furniture vigorously with a cloth, sponge or brush. Wipe off with clear water and let dry.

We recommend to treat the wood afterwards with one of the Auro Garden furniture oils in order to protect your garden furniture and, at the same time, give it a beautiful appearance for the whole summer.

Practical environment protection

With the use of Auro Garden furniture cleaner you contribute to the protection of the environment in your personal sphere. The natural ingredients of this product do not leave any residues. Their biological degradation is completed within 18 days.



Safety advice

Store in a dark, frost-free environment. Keep out of reach of children. Prevent contact with the eyes.

Shelflife: 1 year

Packaging material: Polyethylene

An information from AURO

AURO Pflanzenchemie AG, D-38122 Braunschweig
Phone +49 531- 281 41-0, www.auro.de